



PARTS LIST

CHAIN SAW

G5200

NOTE :

1. Use KOMATSU ZENOAH genuine parts specified in the parts list for repair and/or replacement.
2. KOMATSU ZENOAH does not warrant the machines, those which have been damaged by the use of any parts other than those specified by the company.
3. When placing orders of parts for repair and/or replacement, check if the model name and the serial number are suitable to those specified in the parts list, then use parts number described in the parts list.
4. The contents described in the parts list may change due to improvement.
5. The parts for the machine shall be supplied within ten (10) years after the machine is discontinued.
[It is possible that some specific parts may be subject to change of their delivery term and list price within the limit of ten (10) years after the machine is discontinued. And it is also possible that some parts may be available even after the limit of ten (10) years.]

Fig.1 POWER UNIT




Fig.1 POWER UNIT

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	2880-12111	Cylinder	1	ø45					
2	2880-14111	Inlet Pipe	1						
3	2880-14120	Spring	1						
5	2880-14150	Inner Guide	1						
6	2670-14311	Bracket	1						
7	2670-14320	Screw M5x14	2						
8	2880-14350	Spacer	1						
9	2880-14361	Gasket	1						
10	2670-14211	Gasket, Cylinder	1						
11	4820-13180	Bolt, Cylinder M5x20	4						
12	2810-15220	Bolt, Muffler M5x83	2						
13	2850-15230	Nut, Muffler M5	2						
14	2810-15113	Muffler	1						
15	2670-14130	Screw M5x10	2						
16	3356-15210	Gasket, Muffler	1						
17	2810-15310	Cover	1						
18	848C802101	Crankcase assy	1						
19	3356-21130	• Spring Pin	3						
20	T4012-21240	• Bearing 15x35x11	2						
21	04065-03515	• Snap Ring ø35	1						
22	2670-21210	• Oil Seal 15x35x4.5	1						
23	2670-21220	• Oil Seal 15x28X4.5	1						
24	2850-21230	• Stud	2						
25	2670-21250	• Elbow	1						
26	2810-22511	• Stopper	1						
27	2810-22521	• Stopper	1						
28	848C8021D2	Gasket, Case	1						
29	2670-21320	Screw M5x25	5						
30	2810-22210	Pipe 3x7x105	1						
31	3310-82230	Clip	1						
32	2810-22411	Mat	1						
33	2880-41110	Piston ø45	1						
34	2880-41210	Piston Ring ø45	2						
35	2880-41310	Piston Pin 7.4x11x37.5	1						
36	3350-41320	Snap Ring	2						
37	1400-41410	Needle Bearing 11x15x12.3	1						
38	2670-41510	Washer	2						
39	848C8A4202	Crankshaft Comp.	1						
40	1000-43240	Key	1						

Fig.2 IGNITION, STARTING




Fig.2 IGNITION, STARTING

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	2670-71101	Rotor assy	1						
2	1850-75220	• Ratchet	2						
3	2670-71130	• Spring	2						
4	0308-00040	• Ring	2						
5	3350-43231	Nut M8	1						
6	0290-20820	Washer M8	1						
7	2880-71300	Coil Assy	1						
8	2810-71204	• Coil Comp.	1						
9	2810-71220	•• Cord	1						
10	2670-71230	•• Grommet	1						
11	2810-72110	• Plug cap	1						
12	1400-72121	• Spring	1						
13	2670-71320	• Tube	1						
14	2810-71250	• Grommet	1						
15	2670-14220	Screw M5x20	2						
18	2670-71510	Cord	1						
19	2880-71600	Switch assy	1						
20	2810-71610	• Switch	1						
21	2670-71621	• Switch Cover	1						
22	2880-71630	• Plate	1						
23	2670-14130	Screw M5x10	1						
24	3699-90512	Spark plug (NGK BPM8Y)	1						
25	2810-21270	Plate	1						
26	0260-30410	Screw M4x10	2						
27	2881-75000	Starter assy	1						
28	2810-75110	• Recoil case comp.	1						
29	2810-75120	• Guide	1						
30	2810-75150	• Boss	1						
31	2670-75212	• Reel	1						
32	3317-75300	• Spring comp.	1						
33	2670-75411	• Rope	1						
34	T2041-75420	• Knob	1						
35	T2041-75431	• Collar	2						
37	2881-75440	• Spring B	1						
38	1400-86280	• Washer	1						
39	2670-14220	• Screw	1						
40	2880-75600	Fan cover comp.	1						
42	2880-75620	• Sheet	1						
43	2670-14320	Screw	4						
44	848C8C90C1	Label, Recoil	1						
45	2881-98611	Snow protector	1	OP					

Fig.3 HANDLE




Fig.3 HANDLE

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	2880-32101	Left handle comp.	1						
2	8488251901	Screw M5x19 BT	4						
3	2880-32250	Bracket	1						
4	2670-14130	Screw M5x10	1						
5	2880-32270	Screw M5x8	1						
6	2880-31211	Damper	1						
7	2810-33007	Right handle assy	1						
8	3330-33250	• Stopper	1						
9	3310-33262	• Spring	1						
10	3310-33271	• Knob	1						
11	2810-33280	• Damper (A)	1						
12	2670-75520	• Screw	1						
13	2810-33211	• Gasket	1						
14	2670-33311	• Throttle lever	1						
15	3356-33321	• Throttle spring	1						
16	04025-00524	• Spring pin ø5.2x24	1						
17	848C3033E3	Arm	1						
18	2670-34110	Grip cover	1						
19	8488251901	Screw M5x19 BT	1						
20	2810-25210	Chain catcher	1						
21	2670-14320	Screw M5x14	1						
22	2880-35111	Damper	3						
23	8488251601	Screw M5x16 BT	4						
24	2810-35150	Damper cap	3						
25	2881-35110	Spring	1						
26	2881-35120	Spacer	1						
27	2880-35211	Damper	2						
28	3350-35170	Bolt	2						
29	2880-35250	Cap	2						

Fig.4 FUELING SYSTEMS




Fig.4 FUELING SYSTEMS

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	2880-31101	Cylinder cover	1						
2	2880-31120	• Nut	1						
3	2670-14320	Screw M5x14	5						
4	2854-31513	Label	1						
5	2810-83305	Cleaner cover comp.	1						
6	3356-83322	• Knob	1						
7	3388-83340	• Gasket, cap	1						
8	2810-83500	• Air cleaner comp.	1						
9	2810-83520	•• Seal	1						
10	1600-33130	• Screw	1						
11	2810-83410	• Grommet, Air cleaner	1						
12	2810-83101	Air cleaner comp.	1						
13	2813-31210	Label	1						
14	2880-82310	Guide (I)	1						
15	2880-82350	Guide (HL)	1						
16	2880-82102	Manifold comp.	1						
17	2810-82141	Supporter	1						
18	2880-82210	Screw M5x52	1						
19	2880-82410	Choke rod	1						
20	2670-82421	Grommet, Choke	1						
21	2670-82430	Guide	1						
22	2880-82511	Throttle rod	1						
23	2810-82520	Grommet, throttle	1						
24	848C808536	Fuel pipe assy	1						
25	848C8085R5	• Fuel pipe	1						
26	2850-34350	• Collar	1						
27	3302-85400	• Filter assy	1						
28	2670-34401	Tank cap assy	1						
29	2670-34430	• Gasket, Tank cap	1						
30	2670-34500	Breather assy	1						
31	3350-34540	• Pipe	1						
32	1260-85460	• Clip	1						
33	T2041-75810	Label	1						
34	2811-98501	Air cleaner comp.	1	OP(Felt)					

Fig.5 OIL SYSTEM, CLUTCH




Fig.5 OIL SYSTEM, CLUTCH

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	2841-31801	Oil cap assy	1						
2	2841-31820	• Gasket, cap	1						
3	2670-23101	Oil pipe compete	1						
4	2670-23120	• Pipe	1						
5	2670-23131	• Oil filter	1						
6	2670-23210	Pipe	1						
7	3330-23121	Valve	1						
8	3350-26220	Seal	1						
9	3350-26230	Clip	1						
10	848C806711	Oil pump assy	1						
11	848C8067A1	• Oil pump	1						
12	2670-55120	• Worm Gear	1						
13	2670-55220	Seal	1						
14	2670-55410	Screw M4x14	2						
15	2670-55610	Pump cover	1						
16	2670-55410	Screw M4x14	3						
17	2670-51210	Plate	1						
18	848C805121	Clutch assy	1						
19	3317-51220	• Clutch shoe	3						
20	3317-51231	• Spring	1						
21	2810-51310	Needle bearing 12x15x14	1						
22	2880-51110	Clutch drum	1						
23	3350-51121	Rim 325P	1						

Fig.6 CARBURETOR




Fig.6 CARBURETOR

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	2880-81001	Carburetor assy	1	WT-281A					
2	3306-81380	• Screen	1						
3	2810-81120	• Pump cover	1						
4	3310-81130	• Screw	1						
5	3304-81140	• Gasket, pump	1						
6	1172-81150	• Diaphragm, pump	1						
7	2810-81170	• L needle	1						
8	1491-81160	• L needle spring	1						
9	3310-81230	• Lever	1						
10	3310-81240	• Screw M lever pin	1						
11	1262-81270	• Spring	1						
12	3310-81250	• Pin, lever	1						
13	3310-81280	• Cover	1						
14	3310-81260	• Diaphragm assy	1						
15	3310-81290	• Gasket	1						
16	3356-81310	• Valve, inlet	1						
18	3356-81340	• Throttle valve	1						
19	2670-81410	• Throttle spring	1						
20	2880-81420	• Throttle shaft	1						
21	2630-81460	• Idle spring	1						
22	2670-81430	• Idle screw	1						
23	2880-81331	• H needle	1						
24	3080-81320	• H needle spring	1						
25	3310-81351	• Screw	4						
26	2880-81460	• Choke shaft	1						
27	1148-81390	• Ring	1						
28	3350-81350	• Choke spring	1						
29	3350-81220	• Boll	1						
30	2670-81450	• Choke valve	1						
31	2810-81440	• Throttle lever	1						
32	2880-81470	• Screw, valve	3						
33	2810-06021	Gasket Kit	1						

Fig.7 BREAKING SYSTEMS




Fig.7 BREAKING SYSTEMS

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	2670-25310	Bumper	1						
2	2670-14320	Screw M5x14	2						
3	2810-25421	Plate	1						
4	2670-25430	Screw M4x10	1						
5	2670-25410	Guide	1						
6	3350-53410	Nut M8	2						
7	2881-54003	Chain cover assy	1						
8	848C8053A5	• Chain cover	1						
9	2880-53150	• Stopper	1						
10	2671-53210	• Screw	1						
11	2810-53221	• Nut	1						
12	2671-53230	• Gear	1						
13	2671-53240	• Plate	1						
14	2670-25410	• Guide	1						
15	2670-54630	• Screw M4x12 BT	2						
16	2671-53311	• Protector	1						
17	2880-54112	• Front guard	1						
18	2670-54121	• Pin	1						
19	0308-00030	• Ring	1						
20	2670-54210	• Spring	1						
21	2670-54220	• Pin	1						
22	2670-54231	• Spacer	1						
23	3238-15230	• Washer	1						
24	0308-00040	• Ring	2						
25	2810-54240	• Plate	1						
26	2810-54260	• Spacer	1						
27	2670-54621	• Cover	1						
28	2670-54630	• Screw M4x12 BT	3						
29	2670-54302	• Brake lever comp.	1						
30	2670-54411	• Slide arm	1						
31	2670-54510	• Brake band	1						
32	3356-24140	• Roller	1						
33	2670-54610	• Brake spring	1						
34	2880-54650	• Return spring	1						
35	848C8C90B1	Label, Chain cover	1						

Fig.8 GUIDE BAR, SAW CHAIN, TOOLS




Fig.8 GUIDE BAR, SAW CHAIN, TOOLS

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	2974-52111	Hard nose bar 18"	1	G: .058"					
2	3646-52113-50	Sprocket nose bar 18"	1	G: .058"					
3	3646-52210-50	Chain 18"(21BP-72E)	1						
10	3356-97110	Protector	1						
13	2811-91000	Tool set	1						
14	3345-91110	• Bag	1						
15	3320-91140	• Plug wrench 13x19	1						
16	2670-91150	• Driver	1						
17	3320-97310	• File ø4.8 (3/16")	1						
18	3317-91210	• File	1						
19	3381-91530	• Grip	1						
20	3310-91540	• Gauge	1						
21	2670-96002	Tool set	1	OP					
22	2890-96100	• Puller Assy (for rotor)	1	OP					
23	2670-96210	• Wrench (for clutch)	1	OP					
24	2670-96220	• Stopper (for piston)	1	OP					
25	3350-96230	• Guide (for piston)	1	OP					
26	2670-96240	• Wrench (for clutch assy)	3	OP					
27	2670-96310	• Wrench (M5)	1	OP					
28	2670-96320	• Wrench (M4)	1	OP					
29	2670-96510	• Guide (for brake spring)	1	OP					
30	3350-96620	• Guide	1	OP					
31	2670-96660	• Holder	1	OP					
32	3350-96240	• Gauge	1	OP					
33	2850-96410	• Wrench	1	OP					
34	2810-96710	• Guide (for brake spring)	1	OP					
35	3317-91300	Fuel tank assy	1	OP					
36	3317-91400	Oil tank assy	1	OP					
37	2881-98710	Front damper	3	OP					
38	2881-98720	Rear damper	2	OP					



KOMATSU ZENOAHI CO.

1-9 Minamidai, Kawagoe, Saitama, 350-1192 Japan

PRINTED IN JAPAN

PRINTED ON RECYCLED PAPER
IMPRIMÉ SUR PAPIER RECYCLÉ
GEDRUCKT AUF RECYCLING PAPIER
STAMPATO SU CARTA RICICLATA
IMPRESO EN PAPEL RECICLADO